



# Product Update

JULY 25, 2019

#P104F

Revision 06

---

Applies to Flush doors

## **WOOD GLAZING STOPS, SURFACE APPLIED MOULDINGS, & LOUVERS**

Wood stops<sup>1</sup> for field glazing are secured in place one side only with countersunk brads. The other side are placed in loose for removal during jobsite glass installation. Brad holes are not filled in by VT.

Surface applied moulding may be field applied. Mouldings may be attached with mechanical fasteners and/or adhesives depending on door type.

Factory-installed glazing, mouldings, and louvers are available.

<sup>1</sup>Glazing compound or tape may be required during glass installation to bring the stops on the loose side flush with the face of the door.