



GUIDE TO FILLING OUT VT INDUSTRIES STILE & RAIL MACHINING SHEETS

This guide is intended to aid VT customers in filling out our machining sheets. All applicable boxes should be filled out to ensure the doors get prepped properly. If you have any questions please consult your Order Process Guide or your VT customer service center representative.

1. The date the sheets were prepared by the customer.
2. Name of the person VT should contact with questions.
3. Current page number/total number of pages (example: 1/6 read as page 1 of 6).
4. Check the box indicating Heritage or Artistry.
5. Name of job.
6. VT job number.
7. Core type.
8. Fire rating (example: 20-, 45-, 60-, 90-minute). Rated Stile & Rail doors will be positive pressure.
9. Wood veneer species and cut. (example: Plain Sliced White Maple)
10. Check the box of how you want the stiles finished.
11. Enter frame opening width X height (example: 3'0" X 7'0").
12. Enter prefit door width X height X thickness, allowing for stile clearance, top clearance (typically 1/8"), and undercut from concrete floor. (example: 2'11-3/4" X 6'11-1/4" X 1-3/4").
Note: VT's standard is to undersize the width of a single door 1/4", and to undersize the width of single egress pairs 3/16" per leaf. Double egress pairs should be downsized according to the frame manufacturer's standards. Prefit width should reflect downsizing for continuous hinges, surface edge guards, etc.
13. For the inactive leaf of pairs, enter the flushbolt manufacturer, manufacturer's model number, and size if applicable (example: DCI 945 or Trimco 3917-12").
14. Check if you have a top, bottom, or set of flushbolts.
15. Check box if you have raised or flat panels. Leave blank if you have glass.
16. Check box if you have round slat or chevron louvers.
17. Check VT if VT is installing glass. Check other if glass is being supplied in the field. Leave blank if no glass.
18. Check glass type/thickness for correct stop sizing.
19. List mortised holders/stops with degree of opening and template number (example: GJ104 - 90



- degrees temp. #INST100 Glynn Johnson).
20. Use this box for any miscellaneous hardware or notes (List locations if needed).
 21. List door numbers. Several doors can be listed per line by using a comma (,) between door numbers. Door numbers can only be eight characters long. Single egress pairs should have the active leaf end in -AA with the inactive leaf ending in -II. Double egress pairs should end in -D1 and -D2. Bifolds end in /B1, /B2, etc.
 22. List a swing for every door (RH, LH, RHR, & LHR) on the line behind the door number(s).
 23. List the quantity of doors on the page.
 24. Enter the deadlock location from top of door to centerline of lock. (You can use the top of frame location by subtracting 1/8").
 25. Enter the lock location from top of door to centerline of lock.
 26. As a visual check for yourself and VT, please enter the centerline of strike location from the floor. This could save remaking doors due to misinterpretation or mathematical errors.
 27. List the name of the lock/exit device manufacturer.
 28. List the model number of the lock/exit device.
 29. List trim by number and/or name.
 30. List template number(s).
 31. List lock or exit device backset / strike size (example:2-3/4", 4-7/8", etc.).
 32. Write in stile and rail door type (Example: SS1062, SR 1011, etc). Door type should be on the completed stile and rail door elevation sheet.
 33. Check the appropriate box for sticking.
 34. List bevel required on hinge and lock stile. Standard bevel is 1/8" in 2 on swinging doors, square edges on bifolds. Radius edges also available.
 35. List name of deadlock manufacturer.
 36. List the model number of deadlock.
 37. List template number(s).
 38. List deadlock backset.
 39. List standard strike or keeper size.
 - 40-43. List the top of door to top of hinge locations (Typically subtract 1/8" from the top of frame to top of hinge location).



44. List frame manufacturer (example: Steelcraft, Curries, Ceco, etc.). This will aid you and VT in possibly catching misinterpretation of locations and mathematical errors.
45. List hinge gauge (example: .134, .190, .085, etc).
46. List hinge size (hinge height).
47. List hinge backset on door (typically 1/16" less than the frame backset).
48. List template number of hinge.
49. If VT is to supply the wood frame(s) for the door opening(s) check the box for Wood Frame By VT.
50. If the check box for Wood Frame By VT is checked, enter the Wood Frame Elevation sheet number or sheet name that has the frame information.

Date: 1

Prepared by: 2

Page: 3 /

STILE & RAIL DOOR MACHINING SHEET



VT INDUSTRIES INC.
ARCHITECTURAL WOOD DOORS
800.827.1615
WWW.VTINDUSTRIES.COM/DOORS

Heritage Artistry 4

Job Name: 5

Job #: 6

Core: 7

Rating: 8

Face Material: 9

Stile Finish: 10 -1 Unfinished -2 Finished -4 Painted -9 Primed

Frame Opening Size: 11 X

Prefit Door Size: 12 X X

Flushbolt(s) Number & Template: 13
 Top Bottom Set 14


Panel(s)	Louver(s)	Supplied By	Glass Thickness/Type
<input type="checkbox"/> Raised <input type="checkbox"/> Flat 15	<input type="checkbox"/> Round Slat <input type="checkbox"/> Chevron 16	<input type="checkbox"/> Other <input type="checkbox"/> VT 17	<input type="checkbox"/> 1/4" Tempered <input type="checkbox"/> 3/16" Clear Firelite© <input type="checkbox"/> 1/4" Wire <input type="checkbox"/> Other: _____ 18

Mortise Holders / Stop - Degree of Opening - Template: 19

Other Hardware / Remarks: 20

Door #s	Swing
21	22

Quantity of doors on this page: 23



Allow 1/8" Clearance Elevation: 32

Heritage Sticking
 H1-Ovolo
 H2-Square 33
 H3-Ogee
 Other- Supply Drawing

Artistry Sticking
 A1 A5
 A2 A6 33
 A3 A7
 A4

Bevel
 H.S. 34
 L.S. _____

Lock

Manufacturer: 27

Model #: 28

Trim: 29

Template: 30

BS/Strike: 31

Deadlock


Manufacturer: 35

Model #: 36

Template: 37

Backset: 38

Strike/Keeper: 39



Hinge

Gauge: 45

Size: 46

Backset on Door: 47

Template: 48